



GBS Harness Fuse Board

GBS chassis V1 fuse and relay layout

1	2	3	4	
5	6	7	8	
9	10	11	12	
13	14	15	16	

HORN	MAIN BEAM	DIP BEAM
-------------	------------------	-----------------

WASH PUMP	ECU SYSTEM	FUEL PUMP(S)
------------------	-------------------	---------------------

ISOLATOR	COOLING FAN
-----------------	--------------------

Fuse	Rating	Function
1	25A	ignition
2	15A	ECU system
3	10A	head flash / hazard
4		
5		
6	20A	main beam
7	25A	dip beam / rear fog
8	25A	cooling fan
9		
10		
11		
12	20A	fuel pump(s)
13	15A	wiper / washer
14	15A	side light
15	15A	horn / turn
16	10A	spare